



Domestic Appliances and Personal Care

Service Manual

MSH-coding 8822 004 00000

PRODUCT INFORMATION

Voltage : 100, 120, 220-240 V
Frequency : 50-60 Hz
Power consumption : 900 W
Coloursetting : pink with red parts

SERVICE INFORMATION

For the exploded view, circuit diagram and other information see Service Manual 4822 729 21505 of Coffeemaker HD2000/A.

Warning: The jug is on the bottom marked with HD 2000/B.
The tank housing item 7 and the bottom parts item 28 and 50 are not interchangeable with the ones of HD2000/A

Partslist HD2000/B:

1	4822 441 31356	Tank cover	pink	
2	4822 418 40982	Watercontainer + item 3		
5	4822 462 72114	Valve cap		
6	4822 532 52656	Sealing ring		
7	4822 441 11897	Tank housing	pink	
8	4822 535 93525	Hinge pin	pink	
9	4822 441 31399	Housing	pink	
10	4822 148 60324	Transformer	220-240V	1)
	4822 146 10534	Transformer	100-120V	1)
11	4822 282 30245	Thermostat	135°C	
14	4822 134 41219	Fuse-lamp-unit	220-250V	
	4822 134 10041	Fuse-lamp-unit	100-120V	
15	4822 404 40844	Switch slide		
17	4822 404 40842	Switch lever	red	



18	4822 321 11091	Cord set EU-plug	230V	
	4822 321 11176	Cord set UK-plug	240V	
	4822 321 11175	Cord set CH-plug	220V	
	4822 321 11177	Cord set AU-plug	240V	
	4822 321 11277	Cord set JP-plug	110V	
19	4822 530 51365	O-ring		
21	4822 360 50909	Hose-valve-unit		
22	4822 532 21511	Hose		
23	4822 259 20462	Pump 850W	220-240V	
	4822 259 10205	Pump 850W	110-120V	
	4822 259 10228	Pump 850W	100V	
24	4822 480 50535	Filterholder	black	2)
27	4822 276 13609	Switch	100-250V	
28	4822 442 00757	Bottom cover	pink	
29	4822 462 42156	Foot		
30	4822 441 31376	Contact housing	red	
31	see item 10			
32	4822 441 31377	Contact cover plate	red	
33	4822 441 31359	Lid plate (stainless steel)		
34	4822 441 31358	Tank lid	black	
35	4822 520 40312	Ball		
36	4822 532 61274	Hose		
37	4822 466 62611	Rubber ring		
38	4822 290 81708	Contact strip		
39	see item 38			
40	4822 466 62638	Isolation pieces	(+45)	
41	4822 441 31362	Lid complete	pink	
42	4822 492 71651	Spring bracket		
43	4822 498 10527	Handgrip	red	
44	4822 441 31357	Housing	pink	
45	4822 466 62638	Isolation pieces	(+40)	
46	4822 418 40987	Inner jug	(+47+48)	
48	4822 116 40273	PTC element 24V	(+47)	
49	4822 134 41218	Lamp unit	low-voltage	
50	4822 441 11898	Bottom part		

1) Transformer with build-in self-resetting thermal fuse, wire leads and contact points (item 31)

2) Optional special part for use as an insert in item 24:
4822 480 50501 Permanent filter nylon
4822 480 10104 Permanent filter stainless steel